
Installation Instruction

Sierra Pump Accessory Kit







- TURN OFF all power before opening unit.
 - When working with chemicals, wear adequate protective clothing such as gloves and safety goggles

To Attach to Sierra

- 1. Remove Sierra unit from wall.
- Remove top sliding cover of Add-on pump box and rightmost Sierra pump box by inserting a small screwdriver under the right side of cover. Gently pry off, taking care not to damage the unit or cover.
- Remove all four screws that hold the pump on the face of the unit.
- Punch out right side knockout of rightmost Sierra pump box and left-side knockout of Add-on box by inserting a screwdriver into the slot, punching through the plastic. Rotate and twist the screwdriver to completely remove the knockout.
- 5. Remove adhesive liner from the foam washer and attach to the left side of the Add-on pump as required.

- 6. Fit the pump box into the right side of Sierra, aligning the interlocking tabs in the back.
- Install chase nipple and locknut. Tighten to form proper seal.
- 8. Route the blue and white/blue wires from the Add-on pump box into Sierra through the knockout.
- Attach Quick Disconnect connectors (not shown) from harness to blue wire (-) and the white/blue wire (+) of the Add-on pump.
- Replace pump covers, reinstall screws and top sliding covers.

To Use As Stand-Alone Pump

- 1. Punch out knockout as required for wiring
- 2. Attach wiring using appropriate strain relief.
- 3. Use only 24 VDC to power the pump.



To comply with NSF regulations, sight glass must be used with Sierra sanitizer pumps.



Beta Technology

http://www.beta-technology.com