


# DEMA 154 FAUCET PROPORTIONER



\*ITEMS IN REPAIR KIT  
NO. 100-52

NO.	PART NO.	DESCRIPTION
1 *	150-34	Inlet Screen Washer
2 *	100-29	Button Spring
3 *	100-26	Push Button
4 *	100-36	Button Retainer (1 in Repair Kit Only)
5 *	100-33	Outlet Screen (Conical)
6 *	100-19	Outlet Screen (Flat) (2 Req'd)
7 *	100-24	Metering Screw
8 *	150-6	Adapter Washer
9	150-10	Hose Thread Adapter w/Washer
10	100-12	7/32" ID x 3/8"OD x 8' Lg. Supply Tubing

NO.	PART NO.	DESCRIPTION
11	61-107-2	Ceramic Weight
12	100-16E-1	Foot Valve
13	100-52	Repair Kit

### ACCESSORIES

NO.	PART NO.	DESCRIPTION
14	150-23	Outside Chicago Thread Adapter
15	150-21	Inside Aerator Thread Adapter
16	150-32	Inside Kohler Thread Adapter
17	150-9-2	Irregular Faucet Adapter
18	100-14M	Coupling For 1/4" ID x 8' Lg. Tubing