DEMA Pro-Fill I Sink Dispenser

MODELS PF651GAP, PF651AG, PF651GAP-1M, & PF651AG-1M



Overview

The PRO-FILL I Sink Dispenser mixes water with a cleaning chemical and dispenses the solution into holding containers such as sinks. The dispenser is equipped with an ASSE 1055B Approved backflow device.

Each dispenser can be set up to meet specific application needs with the ability to offer:

- High flow dispensing of a single product
- Supplied metering tips allow for preset dilution ratios
- Chemical dilution ratios up to 7:1
- 4 gallon per minute dispensing

Warnings



All installations must conform to local plumbing codes and use approved backflow prevention devices. A pressure indicating tee is to be installed with existing faucets according to local plumbing codes in the state of Wisconsin and any other state that requires the use of a pressure indicting tee.



ALWAYS WEAR PROTECTIVE CLOTHING AND EYEWEAR WHEN WORKING WITH CHEMICAL PRODUCTS.

Packing List

Part	Description	GAP	AG	JAP-2M	AG-2M	
Number		PF651	PF651.	PF651C	PF651.	
L806	CHEMICAL LABELS	1	1	1	1	
100-15K	METERING TIP KIT	1	1	1	1	
61-107-2	SMALL CERAMIC WEIGHT	2	2	2	2	
100-16E-1	TUBING & FOOT VALVE 1/4" X 8'	2	2	2	2	
61-21	OUTLET TUBE 1/2" X 6'	1	1	1	1	
63-83	OUTLET TUBE 9/16" X 6'	1	1	1	1	
66-53-4	MOUNTING SCREW	1	1	1	1	
66-52	WALL ANCHOR	4	4	4	4	Catto

Operational Requirements

Water Supply Requirements

	Minimum	Maximum		
Water Pressure	20 psi (1.38 bar)	125 psi (8.62 bar)		
Water Temperature	-	*150°F (65.5°C)		
*Caution: 150°F (65.5°C) is "hot" to the touch and must be handled with care.				

Overall Size





I-963 Rev. F-42169

10/03/2016

Installation

Mounting Dispenser Assembly

- 1. Remove the ball valve screw and knob then slide the cover off of the valve assembly.
- 2. Position the dispenser on the wall and mark the four mounting screw locations.
- 3. Install the supplied anchors in the wall and install the screws half way into the anchors.
- 4. Slide the dispenser over the screw heads and tighten down the screws.
- 5. Install the desired metering tip in the elbow as shown.
- 6. Cut the chemical supply tube to length by removing excess tubing. Install
- the supplied ceramic weight onto the tube then install the tube onto the elbow barb. Place the tube end with the ceramic weight and foot valve into the proper chemical container. Note: Chemical container can be no greater
- than 6' (1.83 meters) below the dispenser.7. Cut outlet tubing to desired length and install to proportioner barb. Properly place tubing in sink where chemical is desired.
- 8. Replace the cover, ball valve knob, and tighten the screw.

Water Supply

(Inlet pressure must be between 20 psi (1.38 bar) and 125 psi (8.62 bar)).

1. Attach a garden hose to the water inlet on the unit.

able 1. An Oup & Action Oup Induction Flow Nates w/Standard 1/4 Darb and Fubing												
	163 BAG (4 GPM Flow Rate Air Gap Proportioner)					(4 GPM Flow Rate Action Gap Proportioner)						
	Injection Rates For Viscosities Shown					Injection Rates For Viscosities Shown						
Metering	1 cps		75 cps		200 cps		1 cps		75 cps		200 cps	
Color	Oz/Gal	Ratio	Oz/Gal	Ratio	Oz/Gal	Ratio	Oz/Gal	Ratio	Oz/Gal	Ratio	Oz/Gal	Ratio
Tan	0.30	427-1	0.20	640-1	0.15	853-1	0.33	387-1	0.26	500-1	0.12	1090-1
Orange	0.40	320-1	0.30	427-1	0.25	512-1	0.42	307-1	0.32	430-1	0.17	735-1
Turquoise	0.60	213-1	0.40	320-1	0.30	427-1	0.51	251-1	0.34	382-1	0.19	676-1
Pink	0.80	160-1	0.50	256-1	0.40	320-1	0.78	165-1	0.56	230-1	0.3	422-1
Light Blue*	1.00	128-1	0.70	183-1	0.45	284-1	0.87	147-1	0.67	192-1	0.33	391-1
Brown	1.20	107-1	0.80	160-1	0.50	256-1	0.99	129-1	0.74	174-1	0.37	345-1
Red	1.50	85-1	0.90	142-1	0.60	213-1	1.37	93-1	0.91	141-1	0.44	289-1
White	1.85	69-1	1.10	116-1	0.70	183-1	1.52	84-1	1.04	123-1	0.48	264-1
Green	2.00	64-1	1.25	102-1	0.80	160-1	1.72	74-1	1.22	105-1	0.52	244-1
Blue	2.50	51-1	1.50	85-1	0.82	156-1	2.13	60-1	1.27	101-1	0.54	239-1
Yellow	4.00	32-1	1.85	69-1	0.90	142-1	3.05	42-1	1.71	75-1	0.56	229-1
Black	5.50	23-1	2.00	64-1	0.94	136-1	4.50	28-1	1.96	65-1	0.57	224-1
Purple	8.80	15-1	2.40	53-1	0.96	133-1	7.75	17-1	2.4	53-1	0.59	217-1
Gray	11.65	11-1	2.50	51-1	1.00	128-1	9.86	13-1	2.54	50-1	0.63	204-1
No Tip	16.20	8-1	3.00	43-1	1.20	107-1	19.63	7-1	3.16	40-1	0.67	190-1

Table 1: "Air Gap" & "Action Gap" Induction Flow Rates w/Standard 1/4" Barb and Tubing

*Metering tip color was formerly clear.

Notes: All induction flow rates are based on a water pressure of 40 psi.

(1 cps (centipoises)-viscosity of water, 75 cps-viscosity of light weight detergents, 200 cps-viscosity of most dishwasher detergents) Leaner dilutions can be achieved by ordering DEMA ultra lean metering tip kit 100-15KU.

Ratios as low as 100 parts-per-million can be achieved with the use of a DEMA capillary metering tip. Contact DEMA customer service for more information.

If you are having difficulty achieving the ratio you require, call DEMA and ask for the technical service department.







Operation

The operation of this unit is simple. Once all the correct tubing is in place, simply rotate the correct ball valve knob to the "on" position and let the chemical/water solution fill the sink to the desired level. Now rotate the ball valve fully into the "off" position.

Troubleshooting

F	1	1
Symptom	Probable Cause	Remedy
Proportioner fails to draw	1. Insufficient water supply pressure.	1. 20 PSI is the minimum allowable pressure. Seek
chemical properly.		Plumber if necessary to increase water pressure.
	2. Foot valve has dirt/chemical	2. Soak in hot water to clean.
	build-up.	
	3. Proportioner metering tip clogged	3. Soak in hot water to clean interior passages.
	with dried chemical.	
	4. Mineral deposits are located on	4. Soak nozzle and inlet screen in hot water or
	Air Gap nozzle.	product such as CLR to clean mineral deposits.
	5. Valve not rotated in fully open	5. Always turn knob in fully opened positions.
	position.	
"Air Gap" Proportioner is	1. Mineral deposits are located on	1. Soak nozzle and inlet screen in hot water or
dripping or spraying a mist	Air Gap nozzle.	product such as CLR to clean mineral deposits.
(fan pattern) of water.		
Water valve is not shutting	1. Ball valve not closed.	1. Always turn knob clockwise to fully closed
off completely.		position.
	2. Ball valve has internal leakage.	2. Replace ball valve
Threaded connections are	1. The connection between the sink	1. Shut water supply off first. Carefully tighten the
leaking water.	dispenser and water supply line is	female hose coupling on the sink dispenser to
	too loose or rubber washer is	the inlet water supply line. Do not overtighten.
	missing.	
	2. Backflow prevention devices	2. Tighten loose connection(s) with tools if
	and/or proportioners are too loose.	necessary. Do not overtighten if using tools.
Proportioner continues to	1. Concentrated chemical is	1. Move the concentrated chemical so it is lower
draw chemical after water	positioned higher than the	than the proportioner.
valve is closed.	proportioner.	

Parts List (See pages 4-5)

(COVER, MOUNTING BRACKETS, AND HARDWARE					
NO.	PART NO.	DESCRIPTION				
1	65-38-1	Cover, Dual Valve (Stainless Steel)				
2	65-37-1	Bracket, Valve Retaining (Stainless Steel)				
3	60-67-1	#8 X ¹ /2" Lg. Screw (Type B)				
4	65-36-1	Bracket, Wall Mounting (Stainless Steel)				
5*	L806	Chemical Labels				
6*	L1130	Upper on/off Label				
7*	L1167	Pro-fill unit Label				

*Items not shown



PF651GAP & PF651AG DUAL BALL VALVE ASSEMBLY					
NO.	PART NO.	DESCRIPTION			
1	65-6	¹ /4" NPT Plug			
2	65-30-1	¹ /4" NPT Tee			
3	65-7	¹ / ₄ " NPT Ball Valve with Knob			
4	65-31-3U	Adapter, Garden Hose X ¼" NPT (brass)			
5	65-10	Garden Hose Coupling			
6	65-17-2	Hose Adapter Stem			
7	100-38	Strainer Washer			
8	65-11	Swivel Adapter Kit			
9	81-19-20	Knob Screw			
10	65-2K	Knob			
11	25-137-6U	¹ /4" NPT Nipple			



PF651GAP-2M & PF651AG-2M DUAL BALL VALVE							
	ASSEMBLY						
NO.	PART NO. DESCRIPTION						
1	65-6	¹ /4" NPT Plug					
2	65-30-1	¹ /4" NPT Tee					
3	65-7	¹ /4" NPT Ball Valve with Knob					
4	65-31-3U	Adapter, Garden Hose X ¼" NPT (brass)					
5	25-137-12U	¹ /4" NPT Nipple					
6	61-121	¹ /4" Street Elbow					
7	25-51-12	¹ / ₄ " NPT X 3/8" O.D. Tube Compression Fitting					
8	81-19-20	Knob Screw					
9	65-2K	Knob					
10	25-137-6U	¹ /4" NPT Nipple					



BACK FLOW/PROPORTIONING DEVICES, TIPS, & TUBING					
NO.	PART NO. DESCRIPTION				
1	16-30	ACTION GAP Assembly			
2	61-22-3	Proportioner Assembly (4 GPM) w/Elbow			
3	61-22-3BAG-EL2	AIR GAP Proportioner Ass'y (4 GPM) w/Elbow			
4	100-15K	Metering Tip Kit (14 Sizes)			
5	100-12	¹ / ₄ " I.D. X 8' Lg. Vinyl Tubing			
6	61-107-2	Ceramic Weight (3/8" I.D.)			
	100-16E	Foot Valve Assembly (EPDM) – Std. Equipment			
7	100-16S	Foot Valve Assembly (Silicone) - Available			
	100-16V	Foot Valve Assembly (Viton) - Available			
8	61-21	¹ / ₂ " I.D. X 6' Lg. Vinyl Tubing			
9	63-83	9/16" I.D. X 6' Lg. Vinyl Tubing			



Merchandise Returns

No Merchandise will be Returned for Credit Without DEMA'S Written Permission. Returned Merchandise Authorization Number is Required in Advance of Return.

Product Warranty

DEMA products are warranted against defective material and workmanship under normal use and service for one year from the date of manufacture. This limited warranty does not apply to any products that have a normal life shorter than one year or failure and damage caused by chemicals, corrosion, physical abuse, or misapplication. Rubber and synthetic rubber parts such as "O"-rings, diaphragms, PVC tubing, and gaskets are considered expendable and are not covered under warranty. This warranty is extended only to the original buyer of DEMA products. If products are altered or repaired without prior approval of DEMA, this warranty is void.

Defective units or parts should be returned to the factory with transportation prepaid. If inspection shows them to be defective, they will be repaired or replaced without charge, F.O.B. factory. DEMA assumes no liability for damages. Return merchandise authorization number must be granted in advance of returned units for repair or replacement (See "Merchandise Returns" above).